

## Troubleshooting

	Issue	Cause	Correction
1	The TWINS do not speak simultaneously.	Proper Play Pattern	None - Twins speak together and separately.
2	The TWINS are speaking slowly.	Low battery.	Replace batteries.
3	The MAGICAL SPOON/CUP is not triggering speech.	Wrong position near mouth.	Make sure MAGICAL SPOON/CUP is put directly between lips.
4	The TWINS head and arms are moving slowly.	Low battery.	Replace batteries.
5	The TWINS cannot find each other.	Girl Twin is on wrong side.	Switch the boy and girl position.
6	TWINS are in correct position but not communicating.	Too Far Apart.	Move Dolls within 5 feet of each other.
		Low battery.	Replace batteries.
7	The TWINS head and arms are not moving.	The arms are not positioned right.	Reposition the arms to face forward as per the diagram on the front page of this sheet.
8	New batteries, doll turned on and they don't function.	Programming needs to be reset.	Reload with new batteries and switch the power button to ON.

## IR DISCLAIMERS

- The IR communication distance of the dolls should be kept within 5 ft.
- The IR communication position of the girl doll should always on the right side of the boy doll.
- Strong sun light may affect the IR communication between the Twins.
- The Twins should sit upright for best performance.
- IR works best when transmitters in dolls' ears are pointed at each other.
- These dolls use Infra Red technology. They are designed for indoor use only. The manufacturer does not guarantee that these dolls will work properly under direct sunlight.

## CLEANING THE DOLLS

Use a damp cloth to wipe off the dolls. Do not put dolls in washing machines.

**Please keep these instructions for future reference as they contain important information.**




© 2008 New Adventures LLC, West Orange NJ 07052. MADE IN CHINA.



**TOO CUTE TWINS®** talk, sing, rhyme, joke and giggle together! Just like real twins, these Twins share a special bond - they know and respond to what each other is saying! You will experience hours of entertainment and double the fun with the **TOO CUTE TWINS®** and their magical accessories!

**Please keep these instructions for future reference as they contain important information.**



PART NO.	DESCRIPTION	NO. OF PIECE
A	DOLL	2
B	MAGICAL CUP	1
C	MAGICAL SPOON	1
D	COMB	1
E	BOWL	1

### NOTE:

12 AA batteries are included with this product. For best performance, we suggest installing these batteries for full function playing (6 AA batteries for boy & 6 AA batteries for girl).

For Ages 2+

© 2008 New Adventures LLC,  
West Orange NJ 07052. MADE IN CHINA.

CAUTION: All wire ties are not part of this toy and should be removed before giving it to your child. Color and product may vary from photo. Conforms to the safety requirements of ASTM-F963-03.




## PLAYING WITH THE TOO CUTE TWINS®

**PLEASE NOTE: THE TWINS CAN ONLY COMMUNICATE IF THE GIRL'S POSITION IS TO THE RIGHT SIDE OF THE BOY.**

- To begin playing with the Too Cute Twins®, turn the On/Off switch on the battery box to the ON position. (Refer to Battery Instructions)
  - Place the girl TWIN next to the boy TWIN. The TWINS are now ready for their afternoon and will share a fun rhyme to begin their adventure.
  - The TWINS are so smart, that if you place the girl or the boy TWIN on the wrong side, they will tell you!
- The Too Cute Twins® talk and answer each other
  - When the TWINS tell you that they are hungry or want a snack, it is important to feed them with their MAGICAL SPOON/CUP. The MAGICAL SPOON/CUP can be used at any time during play and will interrupt the TWINS conversation in order to begin the feeding playtime.
- For best performance, keep dolls within 5 feet of each other.
- The **Too Cute Twins®** need lots of love and hugs! Each TWIN doll has a HUG button on their chest. When you HUG them, a special response occurs!
- Each doll has the ability of independent play.
- The **Too Cute Twins®** will be tired at the end of the activities and will ask to take a nap. When they say 'Nite Nite!', the dolls will power down. To re-activate EACH doll, either press the HUG button on each of their chest's or turn the On/Off switch on each of their battery boxes to OFF then back to ON or put the MAGICAL SPOON/CUP to their mouths. This will restart the dialog and actions of each doll.
- If there is no communication between the TWINS they will power down. This will save on battery life. To re-activate EACH doll, either press the HUG button on each of their chest's or turn the ON/OFF switch on each of their battery boxes to OFF then back to ON, or put the MAGICAL SPOON/CUP to their mouths. This will restart the dialog and actions of each doll.



## REMOVAL OF TRY ME FEATURE:

**NOTE:** Try me wire is for in-store demonstration only. Please un-plug the try-me wire from both dolls, and discard, before normal play (note that once the try-me wire is unplugged, it will never plug back in to the original position). Please see diagram 1.



## BATTERY INSTRUCTIONS: ADULT SUPERVISION IS RECOMMENDED WHEN INSERTING OR CHANGING BATTERIES.

- Too Cute Twins®** have one screw-down battery box door for safety and require 6 "AA" batteries per doll.
- Remove the outfit of the twins half-way.
- Make sure the On/Off switch is in the OFF position. Remove the battery box doors with a Phillips® screwdriver.
- Insert 6 "AA" (alkaline) batteries, matching the polarity direction of the batteries as indicated on the inside of the battery box.
- Replace the battery box covers and screw them closed. Turn the On/Off switch to ON and refasten the doll's outfit.
- The twins can start communicating when they are placed together. Girl on left, boy on right when facing.
- The twins will turn to sleep mode if there no action.
- You can re-start the play by pushing the chest button or place the MAGICAL SPOON/CUP into the doll's mouth. This is necessary with both dolls.



### NOTE:

12 AA batteries are included with this product. For best performance, we suggest installing these batteries for full function playing (6 AA batteries for boy & 6 AA batteries for girl).

## BATTERY CAUTIONS: IMPORTANT: ONLY ADULTS SHOULD REPLACE BATTERIES.

- Batteries are not to be recharged.
- Be sure to insert batteries correctly and always follow the toy and manufacturer's instructions.
- Only same or equivalent batteries are recommend for use.
- The supply terminals are not to be short circuited.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Always remove exhausted or dead batteries from product.
- Remove batteries from the product before extended storage.
- Do not use rechargeable batteries.
- Do not dispose batteries in fire. Batteries may explode or leak.



**'Let's care for the environment'**  
The wheellie bin symbol indicates that the product must not be disposed of with other household waste. Please use designated collection points or recycling facilities when disposing of the item